

ATTENTION:

If any components of this unit are broken, or if the unit does not operate properly, please contact LEM Products at

877-536-7763

For more great products or a free catalog go to lemproducts.com



USE & MAINTENANCE

836



1 YEAR WARRANTY

CLEANING AND CARE

TO PREVENT DAMAGE:

- 1. **DO NOT** stand scale or bowl near an oven or other source of direct heat.
- 2. **DO NOT** immerse scale in water.
- 3. **DO NOT** clean with abrasive or chemical agents.
- 4. **DO NOT** allow scale to come in contact with strongly colored foods or acids such as citrus fruit-zest, which can cause damage to the plastic surfaces.
- 5. **DO NOT** put tray in microwave.
- **Note:** Before use, remove the tray and wash it in warm soapy water. Rinse and hand dry. Line the tray or weighing surface with a deli-sheet before weighing.
- 6. The outer casing of the scale may be wiped clean with a damp cloth.
- 7. The table/mechanism of the scale does not require maintenance of any kind.

ZEROING AND WEIGHING



 Place the empty tray provided on the scale and check to ensure the pointer (the arrow-shaped piece on the dial of the scale for registering information) is at the zero mark before weighing.



Adjust the pointer to zero by turning the rotating knob located on the rear of the scale.



3. Tap the pan gently to settle the mechanism. If necessary, re-adjust each time you use the scale.

IMPORTANT WARRANTY INFORMATION PLEASE READ FILL OUT AND RETURN ENCLOSED WARRANTY CARD

THIS WARRANTY COVERS LEM 22 lb. Scale #836

THE WARRANTY IS EXTENDED TO THE ORIGINAL PURCHASER ONLY.

WARRANTY DURATION: This product is warranted to the original purchaser for a period of one (1) year from the original purchase date. EACH UNIT COMES WITH A WARRANTY CARD, WHICH MUST BE FILLED OUT COMPLETELY AND RETURNED IMMEDIATELY, WITH A COPY OF THE PURCHASING RECEIPT. FAILURE TO RETURN YOUR WARRANTY CARD WILL LIMIT WARRANTY TO 90 DAYS WITH PROOF OF PURCHASE.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. The warranty is void if the product has been damaged by accident, misuse, neglect, modification or improper service or repairs by unauthorized personnel. It is also void if damaged in shipment or by other causes not arising out of defects in the materials or workmanship. This warranty does not extend to any units which have been in violation of written instructions furnished. This warranty covers only the product and its specific parts, not food or other products processed in it.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied, and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance under any theory of sort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability or breach of contract. The manufacturer declines all responsibility for damage to persons, things or animals arising from the failure to comply with the norms contained in this manual. The manufacturer reserves the right to make modifications at anytime to the models while maintaining the main characteristics described herein. The manufacturer also declines all responsibility for any errors in compiling this manual.

WARRANTY PERFORMANCE: During the above one year warranty period, a product with a defect will either be repaired or replaced after the product has been inspected by an LEM Service Technician. LEM RESERVES THE RIGHT TO REFUSE WARRANTY PERFORMANCE OR PRODUCT EVALUATION UNLESS THE ORIGINAL SALES RECEIPT OR THE WARRANTY CARD IS ON FILE. The repaired product will be in warranty for the balance of the one year warranty period. No charge will be made for such repair or replacement.

IMPORTANT NOTICE: If any parts are missing or defective, please contact our Customer Service Department for assistance at 877-536-7763. (M-F 8:30am to 4:30pm EST) **DO NOT RETURN TO THE STORE WHERE THE PRODUCT WAS PURCHASED.**

LEM PRODUCTS MERCHANDISE RETURN POLICY WARRANTY SERVICE:

To obtain service under terms of this warranty, please contact us at 877-536-7763 to obtain authorization prior to returning the merchandise. No merchandise will be accepted without prior authorization. Please return the product prepaid in the original packaging if possible, enclose a copy of your receipt, (Keep a copy of your proof-of purchase for your records.) and include a written explanation of the issue. Ship to LEM Products, 4440 Muhlhauser Rd., Suite 300, West Chester, OH 45011. LEM Products is not responsible for damage incurred in shipping, make certain to pack product properly. Return shipping charges are the responsibility of the purchaser. Packages returned to LEM should be insured for the value of the product to cover any damages that may occur during shipping.

Revised July 26, 2016