

## How to use the #829 Vegetable Slicer

Prior to use wash all parts in hot soapy water and dry immediately. (dishwasher safe, top rack)

**Warning: Blades are sharp!**

With the slicer lying face down and flat on the counter, unfold the front and back supports. Turn the slicer over and place on a flat surface with the tall end closest to you.

The sides of the slicer frame have two black adjustment knobs. These knobs adjust the thickness of the slice. They work together, but separately, to move the adjustable plate up and down. When turning the left knob forward, turn the right knob back and move the adjustable plate to the desired thickness and then firmly tighten both knobs by turning the left knob back and the right knob forward.

The slicer comes with several blades for different slicing options. There is a flat blade and crinkle blade which can be used alone or in combination with any of the 3 julienne blades.

**All of these directions are meant to be used with the high end of the slicer directly in front of you.**

Select the straight or crinkle slicing blade. Insert selected blade on the left side of the slicer with the sharp edge towards you, lining up the shape of the blade with the hole. Slide the blade to the right until it clicks into place. Now you can slice.

To remove the slicing blade:

On the left side of the slicing blade holder, you will see a small locking tab. Press this tab down and at the same time push on the right side of the blade holder, until the blade is released. It is easiest using your left thumb to push the tab while using your right thumb to push the blade out.

To julienne your food of choice:

Select one of the 3 julienne blades. Holding the julienne blade by the handle insert it in front of the slicing blade from the right side of the slicer until it locks into place.

To remove the julienne blade:

Using your left thumb, push the tab of the julienne blade holder that is sticking out the left side of the slicer at the same time use your right hand to pull on the handle of the julienne blade holder.

Your slicer comes with a telescoping hand protector/food holder. Always use the hand guard when slicing.

**Warning: severe injury can occur if protector is not used!**

Take food of choice and press it into the food holder so it is held by the prongs. Place the food in the holder on the slicer body and begin quickly sliding the food over the slicing blade(s). **Tip: If food is too long or too large for the food holder cut it to fit properly into the holder.**