




MAXVAC[®]

ROLL HOLDER & CUTTER

1252

INSTRUCTIONS

1




Attach the MaxVac Roll Holder & Cutter to your MaxVac.

2



Insert 2 baffles into the base of the holder, fitting to roll size.

3



With material coming off the bottom of the roll, feed material under the fixed rod and cutting bar. Pull material out long enough to accommodate product you are sealing plus 2-3"

4



While holding one side of the material and pressing down on the razor, run razor across material to cut. Material is ready to be sealed into a bag.